



# Full Spectrum Solutions

UltraLux Clamp On Magnifier Lamp

## Assembly Instructions

Item: UL9322CM

Thank you for purchasing our UltraLux Clamp On Magnifier Lamp. This UltraLux lamp is ideal for precise work in home, office, workshop as well as a lot of other important places. Before using the magnifier lamp, please read the following instructions.

### 1. Important Data:

Magnifier - 7.5" x 6.2", 5 diopter

Voltage - AC110V~60Hz

Tube Type - 2x9W G23

Ballast - AC110V 18W

### 2. How to use:

Clamp the bracket to the edge of any horizontal surface. Insert the bottom stem of the arm into the hole in the bracket. Plug in the magnifier lamp.

### 3. Change of tube:

Switch off the magnifier lamp and unplug.

Take off the transparent tube protection cover.

Replace the old tube with the new one.

Put on the tube protection cover.

### 4. Important for safe use:

Indoor use only.

Humidity: <95%

Never disassemble the magnifier lamp unless you are a qualified electrician.

Lamp must be unplugged while any repairs are made.

The magnifier lamp can only be mounted on a horizontal surface with a thickness from 0.5" ~ 2.5"